

Herelink Important Notes on Joystick


****Three problems were discovered in the current batch of beta version Herelink ****

****We apologize for any inconvenience caused ****

1. Drag down the notifications menu when QGC is running will cause joystick malfunctioning. Therefore, please complete your configurations before take-off. Do not slide or focus at the notifications menu during the flight, in order to avoid joystick malfunctioning.

Notifications menu as shown below:


(DO NOT pull down notification menu during the flight)



2. When selecting flight mode on Herelink QGC, a window will be popped up. Stay focus on the pop-up window will also cause joystick malfunctioning. Therefore, it is better to use buttons (via hardware) instead of touch screen (via software) to switch flight mode during the flight.


Flight mode switching interface as shown below:

(DO NOT click the flight mode option during the flight)



- When selecting "Values" option, joystick will also malfunction. Thus, please do not frequently switching among different options or keep the menu open. If it is necessary to switch during the flight, make it as fast as possible.

Values option as shown below:



7th Jun 2019