



Mixer turns forward motor  
Down or up, and come with reverse motor to steer.

Note:  
"Left" & "Right" will depend on the configuration of your receiver & motors etc, you may need to swap these around. Similarly "FWD" & "REV" may also need to be swapped. The polarity of the output connections will remain correct.

**SCHEMATIC OF INSTALLATION IN TWIN-ENGINEED MODEL**

01248 719353